

Four Eye Light – Manuale Utente

Produzione – Protezione – Prodotto

Riparazione – Garanzia

Nota:

Grazie per aver acquistato questo prodotto a LED.

Prima dell'uso, leggere attentamente questo manuale per garantire sicurezza e prestazioni corrette.

Contenuto della confezione:

- **1x Lampada completa**
 - **1x Manuale di istruzioni**
 - **1x Scheda di garanzia**
-

Scheda di Garanzia del Prodotto

Prodotto: _____

Modello: _____

Data di acquisto: _____

Dati del Produttore

Nome: _____

Telefono: _____

Dati del Rivenditore

Nome: _____

Telefono: _____

Utente finale

Nome organizzazione: _____

Indirizzo: _____

Contatti: _____

Telefono: _____

⚠ Le informazioni sopra devono essere compilate correttamente dall'utente e dal rivenditore. In caso contrario, la garanzia non è valida.

Funzioni dei Canali DMX512 (8 Canali)

1. Dimmer totale – da bianco caldo a bianco
 2. Dimmer lineare da scuro a luminoso
 3. Flash/Strobo – velocità bianco caldo e bianco totale
 4. Selezione effetto: 0-60 (controllo DMX, salto colore, dissolvenza, impulso, ecc.)
 5. Velocità dell'effetto selezionato nel canale 4
 6. Dimmer bianco positivo – da scuro a luminoso
 7. Dimmer bianco caldo – da scuro a luminoso
 8. Dimmer bianco – da scuro a luminoso
-

Impostazione Indirizzo DMX512

Product warranty card

product name		Manufacturing day	
product model		Purchase day	

ultimate user	distributor
name of organization:	contacts:
address:	telephone:
contacts:	
telephone:	affix one's seal

Note: The above blank parts must be truthfully filled in by the end user and the sales store, otherwise there is no warranty. (Warranty period and terms, see the back)

Four eye light

Production protection product
repair says karming

(Please read this instruction manual in detail before using this lamp.)

First of all, thank you for purchasing LED series lamps. Please read this manual carefully before using and operate according to the procedures to avoid personal safety and damage.

Box list: one set of lamps, one instruction manual, one warranty card.

Lighting function design is applicable to: nightclub.DISCO.bar. Home PARTY, etc.

direction for use:

After opening the packing box, carefully check whether the lamp is damaged by transportation, such as whether the screws are loose and whether the lens is broken. Before the power is on, please check whether the position of the lamp is correct and stable, check whether the power supply voltage is the same as that of this product, otherwise the damaged lamp is not in the warranty example, and can be used after the normal check.

This equipment is a level 1 protection equipment, so the bottom line of the power supply must be grounded and completed by professionals. Before use, check whether the supply voltage is normal. If the supply voltage fluctuates greatly, it is recommended to use 110V-230V voltage or voltage regulator

technical parameter:

Rated voltage: AC110 / 230V + 10% Rated frequency: 50Hz~60Hz


Number of lamp beads: 4 colors: positive and white. Warm white

Number of channels: 8 DMX512 channel working environment: indoor, outdoor

Control mode: self-walk, DMX512, master-slave synchronization

product description

1. Graphical part:



- A. 确认键
- B. 加键
- C. 减键
- D. 退出键
- E. 数码管显示窗

2. Operation instructions:

Display the last operation when turning on. Press B / C to select different function effects (refer to the function table). The last two numbers represent the function of this kind.address code.

Or the speed, the parameters of the. Press either B or C to modify the parameter values.

3. Digital display window function control table

4. DMX 8 channel function introduction:

channel	Channel function
channel 1	Total dimming is white warm white total dimming, linear dimming, from dark to bright
channel 2	Floribe speed, white warm white total strobe, from slow to fast
channel 3	Function selection, 0- -60: DMX seven channel control; 61- -120: jump; 121- -180: gradient, pulse; 181- -240: jump, gradient, pulse; 241- -255: voice control
channel 4	Functional speed, functional speed, from slow to fast
channel 5	Positive white dimming, linear dimming, from dark to bright
channel 6	Warm white dimming, linear dimming, from dark to bright
channel 7	Positive white dimming, linear dimming, from dark to bright
channel 8	Warm white dimming, linear dimming, from dark to bright

5. DMX-512 address code setting method:

cresset	start address
1	001
2	017
3	033
4	049
5	065
6	081

➤ Master and slave Synchronization Notes:

1. When the host is used, the lamp will send the DMX-512 signal, which cannot be connected to the DMX-512 console, otherwise it will interfere with each other and cannot run synchronously.

2. Multiple lamps operate mainly and synchronously, among which only one lamp is the main engine, and the other lamps are the slave machine (set to SLAV). Otherwise, it cannot be run synchronously.

Maintenance: It is recommended to use a professional glass cleaning agent and clean it with a flannelette. Keep it clean frequently to obtain the maximum LED brightness output.